

Batterie laden

chargerobin or type unknown

- 1. Connect the power-adapter to the wall socket
- 2. Connect the type-C USB-cable to the power-adapter
- 3. Connect the USB-cable to the plug on the back of Robin

Charge indicator

The LED on the mouth of Robin will show the status of the battery.

While Robin is powered down

Flickering red light	Robin is charging (Robin battery < 50%).
Flickering green light	Robin is charging (50% ≤ Robin battery< 100%).
Constant green light	Robin is off and fully charged.

--	--